




# Wiring Diagram Using a Zone Valve Wired Directly into the Control Box of the Furnace



For illustration purposes only:  
 • Existing thermostat style may vary.  
 • Location of thermostat may vary.

**NOTE**  
 Thermostats must be installed by qualified technician.

