

Furnace must be installed on a noncombustible surface or foundation that incorporates an enclosure that will prevent supply and return lines from possible exposure to sunlight, fire, or physical damage that may be caused by an occurrence outside the furnace enclosure.

	Α	В	С	D	Е	F	G	Н
in.	34	57	49.5	36	48	59.5*	117.5**	14.5
cm	86	145	126	91.5	122	151*	298.5**	37

\* Measurement (F) is from firebox door to chimney inspection cover.

\*\* Measurement (G) includes two 4 ft. chimney sections.

